

ARM Kit Specify ARM Kit where a shallow anchor well is present, and the anchor rope especially needs to be powered out or in. Not needed for all chain rodes. For further information see Windlass accessories on page 36.

Part Number	Description
66810030	V2/V3 Arm Kit
66810031	V4/V5 Arm Kit

V4/V5 Hydraulic Motor/Gearboxes

Part Number	Model	Description	Max Pressure	Flow Rate	Typical Max Pull		Max Line Speed	
					kg	lb	m	ft
68000294	V4/V5	Hyd Mtr/Gearbox	175 bar 2537 psi (cont)	10-40 l/min 2.6-10.6 US gal/min	1100 14 bar	2400 203 psi	21 40 l/min	69 10.6 US gal/min

Hydraulic motor/gearboxes are suitable for use with both V4/V5 and Concept 3 deck units

V Series Gypsy and Gypsy/Drum Specifications

Part Number	Model	Description	Power Option	Motor Watts	Typical Max Pull		Max Line Speed/min		Typical Working Load	kg	lb	Normal Current Draw	Normal Line Speed/min		Weight		Circuit Breaker (Slow Blow)
					kg	lb	m	ft					m	ft	kg	lb	
66810020	V2/V3	Deck Unit Gypsy Only													7.0	15	
66810021	V2/V3	Deck Unit Gypsy/Drum													10.0	22	
66810058	V2/V3	Deck Unit Gypsy Only Manual Recovery															
66810059	V2/V3	Deck Unit Gypsy/Drum Manual Recovery															
68000527	V2	12v Motor/Gearbox	12v	700W	650	1433	21	69	45	100	80A	14	46	9.5	21	90A	
68000538	V2	24v Motor/Gearbox	24v	900W	760	1675	24	79	45	100	45A	16	53	9.5	21	50A	
68000349	V2	Circuit Breaker	12v												Included	90A	
68000348	V2	Circuit Breaker	24v												in above	50A	
66810007	V3	12v Motor/Gearbox	12v	1000W	890	1962	28	92	45	100	85A	18	59	11.5	25	110A	
66810008	V3	24v Motor/Gearbox	24v	1000W	1020	2248	30	98	45	100	60A	20	66	11.5	25	90A	
68000350	V3	Circuit Breaker	12v												Included	110A	
68000349	V3	Circuit Breaker	24v												in above	90A	
66810024	V4/V5	Deck Unit Gypsy Only													13.0	29	
66810025	V4/V5	Deck Unit Gypsy/Drum													15.5	34	
66810060	V4/V5	Deck Unit Gypsy Only Manual Recovery															
66810061	V4/V5	Deck Unit Gypsy/Drum Manual Recovery															
68000534	V4	12v Mtr/Gearbox	12v	1600W	1360	2998	25	82	136	300	125A	15	49	13.5	30	150A	
68000535	V4	24v Mtr/Gearbox	24v	2000W	1600	3528	27	90	136	300	70A	16	53	13.5	30	110A	
68000351	V4	Circuit Breaker	12v												Included	150A	
68000350	V4	Circuit Breaker	24v												in above	110A	
66810011	V5	12v Mtr/Gearbox	12v	2000W	1860	4100	27	89	136	300	120A	17	56	15.5	34	150A	
66810012	V5	24v Mtr/Gearbox	24v	2000W	2000	4410	29	97	136	300	60A	18	59	15.5	34	110A	
68000351	V5	Circuit Breaker	12v												Included	150A	
68000350	V5	Circuit Breaker	24v												in above	110A	

USA Version Part Number - for use in USA Only

V2/V3 Series Windlass Kits*

V2 Part No.	V3 Part No.	Gypsy Size	Description	Power Option
66910030-138	66910036-139	000	Gypsy Only	12V
66910061-140	66910036-142	000	Gypsy Only	24V
66910031-138	66910037-139	001	Gypsy Only	12V
66910062-140	66910072-142	001	Gypsy Only	24V
66910032-138	66910038-139	002	Gypsy Only	12V
66910045-140	66910047-141	002	Gypsy Only	24V
66910060-138	66910071-139	003	Gypsy Only	12V
66910064-140	66910072-142	003	Gypsy Only	24V
66910033-138	66910039-139	000	Gypsy/Drum	12V
66910067-140	66910075-142	000	Gypsy/Drum	24V
66910034-138	66910040-139	001	Gypsy/Drum	12V
66910068-140	66910076-142	001	Gypsy/Drum	24V
66910035-138	66910041-139	002	Gypsy/Drum	12V
66910046-140	66910048-141	002	Gypsy/Drum	24V
66910066-138	66910074-139	003	Gypsy/Drum	12V
66910070-140	66910077-140	003	Gypsy/Drum	24V

* Kits includes: Rocker Switch, Breaker, Dual direction Solenoid, and handle.

V2/V3 Series Windlass Kits*

V2 Part No.	V3 Part No.	Gypsy Size	Description	Power Option
66910078-143	66910094-145	201	Gypsy Only	12V
66910086-143	66910098-146	201	Gypsy Only	24V
66910079-143	66910095-145	202	Gypsy Only	12V
66910087-143	66910099-146	202	Gypsy Only	24V
66910080-143	66910096-145	203	Gypsy Only	12V
66910088-143	66910099-146	203	Gypsy Only	24V
66910081-143	66910097-145	204	Gypsy Only	12V
66910089-143	66910100-146	204	Gypsy Only	24V
66910082-144	66910102-145	201	Gypsy /Drum	12V
66910090-144	66910106-146	201	Gypsy /Drum	24V
66910083-144	66910103-145	202	Gypsy /Drum	12V
66910091-144	66910107-146	202	Gypsy /Drum	24V
66910084-144	66910104-145	203	Gypsy /Drum	12V
66910092-144	66910108-146	203	Gypsy /Drum	24V
66910085-144	66910105-145	204	Gypsy /Drum	12V
66910093-144	66910109-146	204	Gypsy /Drum	24V

* Kits includes: Rocker Switch, Breaker, Dual direction Solenoid, and handle.

THRUSTERS
ANCHORING SYSTEMS
HATCHES & PORTLIGHTS
WINCHES
HYDRAULICS
HARDWARE
STEERING SYSTEMS

36 37

For Switch kits and other accessories please turn to pages 36 & 37.